

Project configuration using NEOc v2.5.4

Typical configuration of a project using NEOc v2.5.4



LDA Audio Tech - Severo Ochoa Nº 31- 29590 MÁLAGA, ESPAÑA. Tlf: +34 952028805. <u>www.lda-audiotech.com</u> / <u>soporte@lda-audiotech.com</u>



Index

1.Description	3
2.Object	3
3.Access	3
4.Project types	4
4.1.Creating Offline project	4
4.2. Charge offline project in the device	6
4.3.Create online project	8
5.System configuration	
5.1. PA/VA Sytem	10
5.2. Power amplifier outputs	
5.3. CobraNet Inputs	13
5.4. CobraNet Broadcast	
5.5. Speaker lines	
5.6. Status inputs and outputs	14
5.7. GPIO	15
5.8.Serial Ports	15
5.9. Flexnet	
5.10. Access Control	17
5.11. PTT config	
5.12. Messages	
5.13.MPS or VAP configuration	19
5.14. Advanced	
5.15.Events	20



1. Description

NEOc is a versatile and easy to use software used for the configuration of the NEO series devices.

2. Object

The object of this document is understanding how the configuration of a NEO project is made using NEOc software.

In the following chapters the necessary steps to do it are detailed.

3. Access

Accede to the aplication NEOc V2.5.4 or newer using the follower user and password:

- User: default
- Password: 1234

NEO	
••• audioTech	



4. Project types

In NEOc there are two possibilities when a project is made:

• Creating an offline project: Once the offline mode configuration is made, it will be possible to upload it in the device.

• Creating an online project: Once the software NEOc is connected to the device, changes made in the software will be made also in the device.

4.1. Creating Offline project

First, the creation of a new project should be created in order to make the required configuration for the installation that should be made.



Once selected, in the following window the devices to add in the project should be assigned:



NEO Configurat	t or - Search Device Jnassian	*\$			×
System Devices:	Export System	+ Add Device:	NEO8060 -	192.168.0.3	e Device
Device Model	Description	IP Address	NEO8060 NEO8250E	FW Version	Last Seen
01 NEO8060	NEO Controller	192.168.0.3			
Search Devices: Discovered Devices:	Filter by model:	NEO8060 • 🗖	Filter by IP: 10	1.100.234.16 to 10.100	0.234.16 C Refresh
Device Medal	Description	ID A debe se		FWM	A
Device Model	Description	IF Address	MAC	PW version	Lastbeen

- 1. Select the device model.
- 2. Configure IP address.
- 3. Asign the device to the project.

In this example, a NEO8060, a NEO8250E and a NEO4500E should be added.

Once assigned the window should be closed in order to continue making the project configuration.



4.2. Charge offline project in the device.

In order to charge an offline project to a device, the following steps must be made:

- 1. Select offline project.
- 2. Select destination device.
- 3. Assign it.
- 4. Export the project.

NEO Configurat	tor - Search Device	s			×
Assign 3º	Jnassign				
System Devices: 49	Export System	+ Add Device: N	EO4500E + 192.1	68.0.5 Remove De	vice
Device Model	Description	IP Address	MAC	FW Version	LastSeen
01 NEO8060 1º	NEO Controller	192.168.13.10	D8:80:39:5B:B5:62	√02.29.01.30	05/03/2021 17:07:41
Search Devices: Discovered Devices:	Filter by model:	NEO8060 🗸 🗹 Fil n 🚺 Add Device	ter by IP: 192.168.1	3.10 to 10.100.234 Change IP: 10.100.234	1.16 C Refresh
Unlink Extensions	(Comment				
Device Model	Description	IP Address	MAC	FW Version	Last Seen
01 NEO8060 2º	NEO Controller	192.168.13.10	D8:80:39:5B:B5:62	√02.29.01.30	05/03/2021 17:07:42



4.3. Create online project

Select the device that the user would like to connect to and click on "Import system". This way, the user can get connected to the device and make the desired changes in the configuration.

X NEO Configurat	tor - Search Devices				×
🖉 Assign 🚺 🖉 l	Jnassign				_
System Devices:	Export System	Add Device: NEC	04500E - 192.16	8.0.5 Remove Device	
Device Model	Description	IP Address	MAC	FW Version	Last Seen
01 NEO8060	NEO Controller	192.168.13.10	D8:80:39:5B:B5:62	√02.29.01.30	05/03/2021 17:03:50
Search Devices:	Filter by model: NEC	08060 🔻 🗹 Filte	r by IP: 192.168.13	.10 to 10.100.234.16	C Refresh
Discovered Devices:	Import System	+ Add Device	Pldentify 0	Change IP: 10.100.234.16	Factory reset
Unlink Extensions					
Device Model	Description	IP Address	MAC	FW Version	Last Seen
01 NEO8060	NEO Controller	192.168.13.10	D8:80:39:5B:B5:62	√02.29.01.30	05/03/2021 17:03:51
					li



5. System configuration

5.1. PA/VA Sytem

By acceding to the menu PA/VA -> Zones you can assign the zone amount used in the project.

It is recommended to name the zones using the name of the place where they will be, and delete the ones that will not be used, using the button "Delete selected zones".

ct View Tools Help									_		_	_	default :
		e 🖸											
PA/VA System	Configuration	Zones	- Configuration										
Sources	Zones	+ Ac	id zones – Delete	e selected zones	. Mute Edit	output channels	Edit override	✓ VA Volumes					
Microphones		-					-						
EMicrophones		Let	(Nome	Description	Power Amplifier	Dirormed	Stote	Volume	CR Mule	Ellise VA volume	A VA Volume	Cuerride	Source
På Microphones		14	. Harris	P. Beschpilon	Outputs	P Discinica	sidio	P rolanic	. more	Pose freedome	Je controlloring	. oremad	
		0001	Oficingt	Zone #1	0001			0.48				No	ONone
Messages		0002	Pasillo	Zone #2	0002			0 dB	i ii	ä		No	0 None
(1) Audio Sources		0003	Almacen	Zone #3	0003			0 dB				No	0:None
(→ Zones		0004	Primera planta	Zone #4	0004	i ii		0 dB	n	i ii		No	0:None
Events		0005	Segunda planta	Zone #5	0005			0 dB				No	0:None
		0006	Tercera planta	Zone #6	0006			0 dB		i i		No	0:None
		0007	Parking	Zone #7	0007			0 dB				No	0:None
		0008	Zone #8	Zone #8	0008			0 dB				No	0:None
		0009	Zone #9	Zone #9	0009			0 dB				No	0:None
		0010	Zone #10	Zone #10	0010			0 dB				No	0:None
		0011	Zone #11	Zone #11	0011			0 dB				No	0:None
		0012	Zone #12	Zone #12	0012			0 dB				No	0:None
		0013	Zone #13	Zone #13	0013			0 dB				No	0:None
		0014	Zone #14	Zone #14	0014			0 dB				No	0:None
		0015	Zone #15	Zone #15	0015			0 dB				No	0:None
		0016	Zone #16	Zone #16	0016			0 dB				No	0:None
		0017	Zone #17	Zone #17	0017			0 dB				No	0:None
		0018	Zone #18	Zone #18	0018			0 dB				No	0:None
		0019	Zone #19	Zone #19	0019			0 dB				No	0:None
		0020	Zone #20	Zone #20	0020			0 dB				No	0:None

Once deleted, the grouped channels should be grouped in a zone. The difference between channels and zones is:

- Channels: Physical place where the PA/VA speakers are connected.
- Zones: Group of channels in a room or place.

In order to select the channels assigned to each zone, you should select the zone and click on "Edit output channels".

Once the channels are selected and added, the changes must be accepted.

Note: Channels from different devices can be added.



X N	IEO Configurator - Zone Editor : Zon	e 0001 - Channels		×
Zone	#0001 - Amplifier Channels			
- De	lete			
ĥ	Device	Name	Label	Zone
0001	0001 - NEO8060 _ 192.168.0.3	Output #1	A0001	0001 Oficinas
0010	0002 - NEO8250E _ 192.168.0.4	Output #10	A0010	
0011	0002 - NEO8250E _ 192.168.0.4	Output #11	A0011	
0012	0002 - NEO8250E _ 192.168.0.4	Output #12	A0012	
0013	0002 - NEO8250E _ 192.168.0.4	Output #13	A0013	
Ampli	fier Channels d			
ld	Device	Name	Label	Zone ^
0007	0001 - NEO8060 _ 192.168.0.3	Output #7	A0007	0007 Parking
8000	0001 - NEO8060 _ 192.168.0.3	Output #8	A0008	
0009	0002 - NEO8250E _ 192.168.0.4	Output #9	A0009	
0010	0002 - NEO8250E _ 192.168.0.4	Output #10	A0010	
0011	0002 - NEO8250E _ 192.168.0.4	Output #11	A0011	
0012	0002 - NEO8250E _ 192.168.0.4	Output #12	A0012	
0013	0002 - NEO8250E _ 192.168.0.4	Output #13	A0013	
0014	0002 - NEO8250E _ 192.168.0.4	Output #14	A0014	
0015	0002 - NEO8250E _ 192.168.0.4	Output #15	A0015	~
				1

5.2. Power amplifier outputs

The options required for the audio channels will be detailed here.

There, the user will be able to select if the channel will be used as backup and assign the channels that, in case of failure, will use the backup channel. (Remember that the wiring shall be done previously, as indicated in the user's manual).

The gain of the channels can be also configured, and activate the amplifier supervision that will warn the user in case of a failure.

Configuration	Powe	er Amplifier Outp	outs - Configura	tion														
Info		lute 🖌 Edit	equalizer															
Audio Inputs	<u>.</u>		~			Zone	Zone	Output	Total	Output				Amplifier				Spare
Power Amplifier Outputs	Id	Device	✓Name	4	one	Volume	Mute	Volume	Volume	Mute	vumeter	Loudness	▶ Eq	Supervisor	state	ls spare	Spare Channel	active
Cobranet - Inputs	0001	NEO8060 (1)	Linea 1	1		0 dB		-5 dB	-5 dB			2		•			None	
Cobranet - Broadcast	0002	NEO8060 (1)	Linea 2	2		0 dB		-2 dB	-2 dB					✓			None	
Secolor Lines	0003	NEO8060 (1)	Linea 3	3		0 dB		-1 dB	-1 dB								None	
speakerLines	0004	NEO8060 (1)	Linea 4	4		0 dB		-10 dB	-10 dB			•					None	
Status Inputs and Outputs	0005	NEO8060 (1)	Linea 5	5		0 dB		-5 dB	-5 dB			2					Channel 8	
GPIO	0006	NEO8060 (1)	Linea 6	6		0 dB		-6 dB	-6 dB								Channel 8	
Cardial Dauta	0007	NEO8060 (1)	Linea 7	7		0 dB		0 dB	0 dB			✓		•			Channel 8	
Serial Ports	0008	NEO8060 (1)	Backup					0 dB	0 dB									
FlexNet																		
Access Control																		
PTT Config																		
Advanced																		
O View																		
Logs																		



5.3. CobraNet Inputs

In case of having CobraNet sources, they will need to be configured in NEO8060.

In order to do that, the user should indicate the bundle used for each channel.

For example, if the user uses ZES22 matrixes with audio inputs that will be distributed throug CobraNet to NEO devices, those inputs shall be included in NEO.

Configuration	New Cobranet Input		
Info	+ Add		
Audio Inputs	Name	Description	ZBundle ZChannel
Power Amplifier Outputs	ZES22	Entrada 4	150 4
Cobranet - Inputs	Cobranet - Inputs		
Cobranet - Broadcast	- Remove selected		
Speaker Lines	Id ZName	Rescription	Rundle Channel
Status Inputs and Outputs	D009 7ES22	Entrada 1	150 1
GPIO	0010 ZES22	Entrada 2	150 2
Serial Ports	0011 ZES22	Entrada 3	150 3
FlexNet	0012 ZES22	Entrada 4	150 4
Access Control			
PTT Config			
Advanced			
O View	1		
Logs	1		

5.4. CobraNet Broadcast

This menu allows to configure the way in which the system controller transmits his own audio sources though a CobraNet packet to the rest of the devices in the system (Extensions).

If the system has only a NEO Master, it is not necessary to make modifications, but if it has more than one, the user shall configure them according to their needings.

Configuration	Cobranet - Broadcast	
Info	Parameter	✓ Value
Audio Inputs	Local sources broadcast	Enabled Dinamic
Power Amplifier Outputs	Private Mode	Disabled
Cobranet Inputs	Transmission bundle	100
Cobraner - Inpols	Input 0001	Enabled
Cobranet - Broadcast	Input 0002	Enabled
Speaker Lines	Input 0003	Enabled
Status Jacouts and Outsuts	Input 0004	Enabled
status inpuis and Outpuis	Input 0005	Enabled
GPIO	Input EMIC	Enabled
Serial Ports	Input MSG1	Enabled
FlexNet	Input MSG2	Enabled
Access Control		
PTT Config		
Advanced		
O View		
Logs		

5.5. Speaker lines

In this table, we can activate line supervision according to the type of end of line device installed on the line.

Channel protection can also be activated. This means that, when a line has a failure, the



channel will pactivate its own protection in order not to make the amplifier break.

Once active, the line measure is made at 19,5-20 Khz and calibrated using the desired tolerance.

Configuration	Sp	eaker l	Lines									
Info	Þ	Calibra	ate selected lines									
Audio Inputs	In	pedan	nce Lower Tolerance (%) :	15 📮 Impedance Upper Tolerance (%) : 15 🌲								
Power Amplifier Outp	uts	-				1	Delet		Alexandread and	All sectors of		
Cobranet - Inputs	ld	No	ame	Line status	EOL Inputs	Measure	System	Nominal	Impedance	Impedance	Measured Impedance	Impedance Deviation
Cobranet - Broadcast					(1) 217	(TFL2)	(TFL2)	mpeddice	A	В	mpoddinoo	bottalloli
Speaker Lines	00	01 Lin	nea 1		None	Single Line	2	166 ohm				
Status Inputs and Outp	00 uts	02 Lin	nea 2		None	None		166 ohm				
	00	03 Lin	nea 3		None	Class A	V	166 ohm	0 ohm	0 ohm		
GPIO	00	D4 Lin	nea 4		None	None		166 ohm				
Serial Ports	00	05 Lin	nea 5		None	A+B		166 ohm	0 ohm	0 ohm		
ElevNet	00	06 Lin	nea 6		None	None		166 ohm				
TRAINET	00	07 Lin	nea 7		None	None		166 ohm				
Access Control	00	08 Ba	ickup	Spare Channel								
PTT Config												
Advanced												
O View												
Logs												

5.6. Status inputs and outputs

This menu can activate the supervision of the dry contacts for the fire alarm panel or the batteries.

It can also indicate the type of signal and configuration of the status outputs that can be integrated in a central, software management, etc.

When the fire alarm panel or the battery charger configurator supervision is activated, in case of failure, the device will indicate it.

Configuration	Status Outputs			
Info	Status Outputs (Status Out) - Configuration	DIS steady - FLT blink	~	N/C Mode: 🛛
Audio Inputs	Rec-Out Active High:			
Power Amplifier	Dutputs			
Cobranet - Input	Status Inputs			
Cobranet - Broa	Cast General CIE entry point 1 : System Controller [15	92.168.0.3] 🗸		
Speaker Lines	CIE Auto-Reset:			
Status Inputs and	Outputs Description Line Fault	Supervision	▼N/C Mode	State
GPIO	RESET			
Serial Ports	EMERGENCY	~		
FlexNet	ZONE 1			
	ZONE 2			
Access Control	ZONE 3			
PTT Config	ZONE 4			
Advanced	ZONE 5			
	ZONE 6			
• View	ZONE 7			
Logs	ZONE 8			
	AC fault			
	Battery fault	✓		
	DC fault			

5.7. GPIO

Here the user may configure the GPIO estate to configure it later using events.

Options are: input or output.



Configuration	GPIO					
Info	ld Name	Function	State			
Audio Inputs	0001 G01	Output	Low			
Power Amplifier Outputs	0002 G02	Input	Low			
Cobranet - Inputs	0003 G03	Input	Low			
Coherent Broodcast	0004 G04	Input	Low			
Cobranet - broddcast	0005 G05	Input	Low			
Speaker Lines	0006 G06	Input	Low			
Status Inputs and Outputs	0007 G07	Input	Low			
CRIO	- 0008 G08	Input	Low			
GPIO	0009 G09	Input	Low			
Serial Ports	0010 G10	Input	Low			
FlexNet	0011 G11	Input	Low			
	- 0012 G12	Input	Low			
Access Control	0013 G13	Input	Low			
PTT Config	0014 G14	Input	Low			
Advanced						
O View						
Logs						

5.8. Serial Ports

In this section, the configuration of the serial port included in the NEO8060 will be shown. If no integration is carried out, it is not necessary to configure it, and the user could use it as default.

Configuration	Serial Ports		
Info	Parameter	✓ Value	
Audio Inputs	PA Serial Port (ETX) VCC Special Mode	✓ ✓	
Power Amplifier Outputs	PA Serial Port (ETX) Baud rate	19200	
Cohranat Januta	PA Serial Port (ETX) Parity	Even	
Cobraner - Inpols	PA Serial Port (ETX) Stop bits	1	
Cobranet - Broadcast	PA Serial Port (ETX) Mode	RS-485	
Speaker Lines	VA Serial Port Baud rate	19200	
Status laguda and Outputs	VA Serial Port Parity	Even	
Status inputs and Outputs	VA Serial Port Stop bits	1	
GPIO	VA Serial Port Mode	RS-485	
Serial Ports			
FlexNet			
Access Control			
PTT Config			
Advanced			
O View			
Logs			
i	-1		



5.9. Flexnet

VLAN configuration if necessary, as the default is configured as follows:

- VLAN Data: 1
- VLAN Audio: 2

The "Enable Subnet Broadcast Mode" parameter enables broadcast communication to each broadcast address on the Ethernet subnet configured by the devices. This may be necessary in the configuration of certain networks due to advanced traffic filters.

Configuration	FlexNet	
Info	Parameter	V
Audio Inputs	VLAN Data	1
Power Amplifier Outputs	VLAN Audio	2
Cobranet - Inputs	Enable Subnet Broadcast Mode	
Cobranet - Broadcast		
Speaker Lines		
Status Inputs and Outputs		
GPIO		
Serial Ports		
FlexNet		
Access Control		
PTT Config		
Advanced		
O View		
Logs		

5.10. Access Control

This tab allows you to specify and modify the PIN numbers that allow access to the different levels of the NEO touch screen menus.

By default, no PIN is requested to access any level. For EN54-16 installations, a PIN must be set for each access level.





5.11. PTT config

By default, the NEO's front PTT microphone is supervised and does not produce any ding-dong or ringing prior to voice output. This is a requirement of the EN54-16 standard. Optionally, these settings can be modified from this tab.

ΰ	Configuration	PTT Config	
	Info	Name	✓ Value
	Audio Inputs	PA ding-dong enabled	No
	Power Amplifier Outputs	VA ding-dong enabled	No
	Cobranet - Inputs	Disable PTT mic supervision	No
	Cobranet - Broadcast		
	Speaker Lines		
	Status Inputs and Outputs		
	GPIO		
	Serial Ports		
	FlexNet		
	Access Control		
	PTT Config		
	Advanced		
o	View		
	Logs		

5.12. Messages

This section must be done once the equipment is online, as it loads and assigns the messages to be used in the work.

Click on "send audio file" to add the audio files to be used.

Once added, it is necessary to assign it as an EVAC or ALERT message. To do this, select the message and click on the set EVAC or set ALERT button.

Configuration	Messages - Configuration				
Message Transfer	+ Sending audio files. France selected Set EVAC Set ALER				
	ÎÎ VA	Name	Size	Duration	Sample Rate
	0001 ALERT				
	0002	REC_ALERT	550 KB	00:11	24 KHz
	0003	M1_ALERTA_INTERIOR 48KHz_24bits	645 KB	00:13	24 KHz
	0004	M2_EVACUACION 48KHz_24bits	592 KB	00:12	24 KHz
	0005	M3_CONFINAMIENTO 48KHz_24bits	645 KB	00:13	24 KHz
	0006	M4_FIN DE EMERGENCIA 48KHz_24bi	270 KB	00:05	24 KHz
	0007	SIMULACRO	445 KB	00:09	24 KHz
	0008 EVAC	TEST MEGAFONIA	877 KB	00:18	24 KHz
	0009	Locucion CONFINAMIENTO	1007 KB	00:21	24 KHz
	0010	Locucion EVACUACIN	697 KB	00:14	24 KHz
	0011	AviaVox - Sp - PSA-16 - after I	369 KB	00:07	24 KHz
	0012	ms1_fr_LDA	216 KB	00:04	24 KHz
	0013	ms2_fr_AL	446 KB	00:09	24 KHz
	0014	ms3_fr_EV	336 KB	00:07	24 KHz



5.13.MPS or VAP configuration

The grouping of the zones to be made when an MPS or VAP call button is pressed. Simply double click on the required zone and add the group of zones to be called.

Configuration	Buttons					
General	▶ EditIonet_					
Zone Buttons	Îd Button Panel	Name	Zone Id		^	
	1 Main	Oficinas	0001			
	2 Main	Pasillo	0002			
	3 Main	Almacen	0003			
	4 Main	Primera planta	0004			
	5 Main	Segunda planta	0005			
	6 Main	Tercera planta	0006			
	7 Main	Parking	0007			
	8 Main					
	9 Extension 1					
	10 Extension 1					
	11 Extension 1					
	12 Extension 1					
	13 Extension 1					
	14 Extension 1					

5.14. Advanced

Advanced configuration options are only available to users logged in as installers.

In terms of system configuration, only the following items will be used:

- Audio message sample rate: Allows you to set the sample rate of the loaded audio files. This parameter is volatile, it will not be saved in the project nor in the devices, and it is reset to 24KHz when the application is started. Possible values:
 - 24 KHz: Default.
 - 48 KHz: Higher quality. The higher 48 KHz sampling rate of the message may reduce the performance of the device.
- Enable echo for UDP command triggers: Enables echo mode in the event handler and the trigger will be activated through a UDP command.
- Enable Overrides and VA Volumes with PA Mics: Enables the activation of the Override output (used for attenuator cancellation) for PA microphones (ACSI or PTT), depending on the zone selection where the floor is granted. Those zones also get VA Volumes.



5.15.Events

NEO has enormous flexibility to adapt the system to a multitude of requirements thanks to the Event module. The Events module is a creation centre to automate some feature modifications, according to the individual performance needs of the system.

See section 2 point 5 for the events.

To get further information, please check our support website https://support.lda-audiotech.com/