

A. Correction of errors in the system

- **BOOTING ERROR/ DOES NOT START**

After checking the power supply/ battery/ switch button:

OPTION 1: you will need a USB hub, a mouse, a keyboard, and a flash drive for the reparations with software:

1. INSERT FLASH DRIVE + keyboard + mouse in the USB hub and connect the hub to the CC-1000 USB port (you may need to connect the flash drive to the internal USB)
2. TURN ON the system, pres f10, select the flash drive (it is possible that a change of bios will be necessary with "F2" or "DEL")
3. In YUMI, select "Other os and tools"
4. Select "hires boot"
5. Select "mini windows xp"
6. Go to "Men Start", "Programs", "Check disk" and click on "C:" when the pop-up window. Close when finished.
7. Open the USB in the explorer, go to "Tools", "Defrag", "mydefrag.exe"
8. Select "only defragment", in C :(LDA) and " "close when finished"
9. SHUT DOWN THE SYSTEM
10. TAKE OUT THE USB
11. TURN ON NORMALLY

If you have any doubt please contact our Support Department at LDA

soporte@lda-audiotech.com